

# Operating Instructions



# Bubble Machine

**Note:** Always follow all safety instructions affixed to this machine.

1. The Bubble Machine must be used horizontally on a level surface, ensuring that the bubbles are not shooting directly at anyone's face or above areas of heavy traffic as bubble fluid leaves a slippery surface. The machine must not have more than a 5-degree angle of inclination.
2. This machine **requires a dedicated 15-amp outlet.**
3. Place the machine on a level surface and pour approximately 1 cup of bubble juice into the tank. Now plug in the unit.
4. To avoid fluid from becoming contaminated, replace the cap after each use.
5. If you experience low or no output, unplug immediately. Check the fluid level, external fuse, and main power supply. If it appears to be ok, plug it in again. If you cannot determine the cause of the problem, contact us immediately.

## Clean up:

- After use, ensure all the fluid is drained before moving. It will help reduce costly parts replacement and repair charges.
- While the unit is unplugged, empty all the bubble fluid, rinse with warm water, plug the unit in, and run until all wands are residue-free. The unit's body may be cleaned with a soft, damp cloth.

## Caution:

- Do not obstruct the bubble wands.
- Never allow children to place fingers inside the front of the machine.
- Do not leave the machine unattended. Bubble fluid produces slippery surfaces on the floor.
- Never drink the fluid. If it is ingested, call your doctor immediately.
- If fluid comes in contact with eyes or skin, rinse thoroughly with water.
- Beware of overfilling or spillage.

**For any questions or concerns, be sure to contact us immediately.**

**Thank you for your business!**

1155 Route 9  
Wappingers Falls, NY  
(845) 298-0011



1 Precision Road  
Danbury, CT  
(203) 744-2295